

## ADQ7-FW2DDC firmware datasheet



*ADQ7-FW2DDC: application-specific firmware including digital down-converters for radio applications:*

- *Digital Down Conversion*
- *Decimation*
- *Streaming data*
- *Multi-channel synchronization*
- *Differential / single-ended input*
- *Two analog inputs*
- *Two digital radio channels*
- *Option with open FPGA.*


*Applications:*

- *RF system*
- *Channel sounder*
- *RF recording*
- *Satellite monitoring*
- *Radar*
- *Semiconductor RF test*
- *Spectrum monitoring*
- *Test and measurement*
- *RF production test*
- *5G*

## 1 Block diagram

The purpose of the ADQ7-FW2DDC firmware option is to implement an efficient radio receiver for a general purpose radio architecture. The structure of the ADQ7-FW2DDC is shown in [Figure 1](#).

In order to achieve high bandwidth, ADQ7-FW2DDC benefits from SP Devices' powerful interleaving technology ADX. ADX removes typical interleaving artifacts. The result is a unique instantaneous bandwidth of up to 2.5 GHz with high linearity.



#	DESCRIPTION	REF
a	There are two analog inputs for receiving either, I and Q, two RF channels, or a differential RF signal. The analog front-end is either DC- or AC-coupled.	<a href="#">Table 1</a>
b	The high performance A/D converters are interleaved to reach higher instantaneous bandwidth.	<a href="#">Table 1</a>
c	ADX is SP Devices proprietary IP for interleaving correction of A/D converters which enable the unique wide band performance of ADQ7.	<a href="#">Table 2</a>
d	The quadrature mixer transforms the center frequency of the RF signal to the pass-band of the decimation filters.	<a href="#">Table 3</a>
e	The decimation reduces the sample frequency and increase SNR in the signal band.	<a href="#">Table 4</a>
f	This user-defined filter reduces the bandwidth and the noise level. The filter can also implement an equalizer or IQ balance.	<a href="#">Table 5</a>
g	The FIFO handles the transfer of data from the real-time data acquisition to the PC.	
h	The connection to the host PC is using PCIe standard for both PCIe and PXIe systems.	

**Figure 1: Principle of the ADQ7-FW2DDC.**

## 2 Technical data

All values are typical unless otherwise noted.

**Table 1: General parameters**

ADQ7-FW2DDC		
<b>Key parameters</b>		
Analog input channels		2
Digital output channels		2
Digital signal representation low decimation factor	[bits]	16, 32
Digital signal representation high decimation factor	[bits]	32
Firmware input bandwidth	[GHz]	5
Firmware output bandwidth max	[GHz]	5
Sustained streaming bandwidth	[GHz]	1

**Table 2: ADX parameters**

ADQ7-FW2DDC		
Time interleaving spur level up to 5 GHz	[dBFS]	-60

**Table 3: NCO parameters**

		ADQ7-FW2DDC
Frequency resolution <sup>1</sup>	[Hz]	1.1642
Spur level	[dBFS]	-95

1. Computed as (sampling rate / 2) / 2<sup>31</sup>.

**Table 4: Decimation parameters**

		ADQ7-FW2DDC
<b>DDC 1 and 2<sup>1</sup></b>		
Minimum decimation factor		2 <sup>0</sup>
Maximum decimation factor		2 <sup>34</sup>
Pass band ripple	[dB]	0.01
Stop band attenuation	[dB]	80
Bandwidth, pass band		80 %


1. Example: The input to the DDC is at 5 GSPS and a Nyquist bandwidth of 2.5 GHz. A decimation of 2<sup>3</sup> = 8 times means that the output from the DDC is 0.625 GSPS and a Nyquist bandwidth of 0.3125 GHz. The pass band (80%) is then 0.25 GHz.

**Table 5: Equalizer parameters**

		ADQ7-FW2DDC
Filter length	[taps]	5
Maximum filter coefficient		2-2 <sup>14</sup>
Minimum filter coefficient		-2
Filter coefficient length	[bits]	16
Input data word length maximum	[bits]	25

### 3 Related products

The ADQ FPGA Development Kit for ADQ7-FW2DDC opens the FPGA for the user to include custom real-time signal processing. The ADQ FPGA Development Kit is purchased separately. Please contact a Teledyne SP Devices sales representative for information about availability.


**Figure 2: ADQ7-FW2DDC with User Logic 1 and User logic 2 for ADQ Development Kit.**

### 4 Compatible hardware

ADQ7-FW2DDC is compatible with

- ADQ7WB-PXle
- ADQ7WB-PCIe
- ADQ7DC-PXle in dual channel mode
- ADQ7DC-PCIe in dual channel mode
- ADQ7DC-USB in dual channel mode

## Important Information

Teledyne Signal Processing Devices Sweden AB (Teledyne SP Devices) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to Teledyne SP Devices' general terms and conditions supplied at the time of order acknowledgment.

Teledyne SP Devices warrants that each product will be free of defects in materials and workmanship, and conform to specifications set forth in published data sheets, for a period of one (1) year. The warranty commences on the date the product is shipped by Teledyne SP Devices. Teledyne SP Devices' sole liability and responsibility under this warranty is to repair or replace any product which is returned to it by Buyer and which Teledyne SP Devices determines does not conform to the warranty. Product returned to Teledyne SP Devices for warranty service will be shipped to Teledyne SP Devices at Buyer's expense and will be returned to Buyer at Teledyne SP Devices' expense. Teledyne SP Devices will have no obligation under this warranty for any products which (i) has been improperly installed; (ii) has been used other than as recommended in Teledyne SP Devices' installation or operation instructions or specifications; or (iii) has been repaired, altered or modified by entities other than Teledyne SP Devices. The warranty of replacement products shall terminate with the warranty of the product. Buyer shall not return any products for any reason without the prior written authorization of Teledyne SP Devices.

In no event shall Teledyne SP Devices be liable for any damages arising out of or related to this document or the information contained in it.

TELEDYNE SP DEVICES' EXPRESS WARRANTY TO BUYER CONSTITUTES TELEDYNE SP DEVICES' SOLE LIABILITY AND THE BUYER'S SOLE REMEDY WITH RESPECT TO THE PRODUCTS AND IS IN LIEU OF ALL OTHER WARRANTIES, LIABILITIES AND REMEDIES. EXCEPT AS THUS PROVIDED, TELEDYNE SP DEVICES DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT.

TELEDYNE SP DEVICES DOES NOT INDEMNIFY, NOR HOLD THE BUYER HARMLESS, AGAINST ANY LIABILITIES, LOSSES, DAMAGES AND EXPENSES (INCLUDING ATTORNEY'S FEES) RELATING TO ANY CLAIMS WHATSOEVER. IN NO EVENT SHALL TELEDYNE SP DEVICES BE LIABLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING LOST PROFIT, LOST DATA AND THE LIKE, DUE TO ANY CAUSE WHATSOEVER. NO SUIT OR ACTION SHALL BE BROUGHT AGAINST TELEDYNE SP DEVICES MORE THAN ONE YEAR AFTER THE RELATED CAUSE OF ACTION HAS ACCRUED. IN NO EVENT SHALL THE ACCRUED TOTAL LIABILITY OF TELEDYNE SP DEVICES FROM ANY LAWSUIT, CLAIM, WARRANTY OR INDEMNITY EXCEED THE AGGREGATE SUM PAID TO SP BY BUYER UNDER THE ORDER THAT GIVES RISE TO SUCH LAWSUIT, CLAIM, WARRANTY OR INDEMNITY.

### Worldwide Sales and Technical Support

[www.spdevices.com](http://www.spdevices.com)

### Teledyne SP Devices Corporate Headquarters

Teknikringen 6  
SE-583 30 Linköping  
Sweden

Phone: +46 (0)13 465 0600

Fax: +46 (0)13 991 3044

Email: [info@spdevices.com](mailto:info@spdevices.com)

Copyright © 2020 Teledyne Signal Processing Devices Sweden AB. All rights reserved, including those to reproduce this publication or parts thereof in any form without permission in writing from Teledyne SP Devices.